Installation Instructions

TABLE LAMP ITEM NO.:1F747

CAREFULLY PULL OUT EXCESS POWER CORD FROM THE LAMP BASE WHILE ASSEMBLING TO PREVENT THE CORD FROM BECOMING TWISTED.

ASSEMBLY INSTRUCTIONS:


1.PULL THE "CORD" FROM THE BOTTOM OF "LAMP BASE" SCREW"NECK" UNTIL TOUCHED TOP OF LAMP BASE

- 2.PUT "SHADE" ONTO "SOCKET"
- 3.SCREW "SHADE"WITH "SOCKET RING"TIGHTLY
- 4.PLEASE USE TYPE "A" MAX 60 WATT BULB (BULB NOT INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

MADE IN CHINA



ALTERNATE SHADE SPECIFICATION

Critical Bulb-to-Shade Spacing for Open Top / Open Bottom Shades
For your safety, follow the dimensions shown in the chart below.

* * W A R N I N G * * The recommended shades shown on the back of this lamp package are properly sized for use with this lamp. If an Alternate Shade is used, measurements must be checked according to the specifications below. Caution: Using an oversized shade may cause fixture to easily tip over.

AT NO TIME SHOULD THE *CYLINDER DIAMETER (CD) AND **CRITICAL RADIUS (R) MEASUREMENTS OF YOUR ALTERNATE SHADE BE LESS THAN THE MEASUREMENTS NOTED BELOW, AS THIS MAY CAUSE A FIRE HAZARD.

	Lamp holder base size	Bulb		*(CD)Cylinder Diameter		**(R) Critical Radius		(H)Lamp certerline length	
		Wattage	Туре	Inches	(mm)	Inches	(mm)	Inches	(mm)
	Medium	25W	Α	3	(76.2)	1-5/8	(41.3)	2-3/4	(69.8)
1	Medium	40W	Α	3.5	(88.9)	2	(50.8)	3-1/4	(82.5)
11)	Medium	60W	Α	3.5	(88.9)	2-1/2	(63.5)	3-1/4	(82.5)
	Medium	75W	Α	3.5	(88.9)	2-7/8	(73.0)	3-1/4	(82.5)
	Medium	100W	Α	4	(101.6)	3-1/2	(88.9)	3-1/4	(82.5)
	Medium	150W	Α	4.5	(114.3)	4-3/4	(120.7)	3-1/4	(82.5)